

FEATURES

- 2¼"/58mm Paper Roll
- 90mm Print Speed
- 12VDC RJ Cash Drawer I/O connector port
- Applicable POS Terminal I/O connector ports

CONTENTS IN BOX WITH PRINTER

- (1) Interface Cable (IFC):
 - (1) Model RP58P-Parallel interface cable
 - (1) Model RP58S-Serial interface cable
 - (1) Model RP58U-USB interface cable
 - (1) Model RP58E-Ethernet interface cable
- (1) AC/DC Power Supply Adapter, 110/240 AC, 3Amps
- (1) AC/DC Power Supply Adapter Power Cord
- (1) Starter Paper Roll
- (1) Software Driver CD




Model RP58P
Parallel I/O Port


Model RP58S
Serial I/O Port

Model RP58U
USB I/O Port


Model RP58E
Ethernet I/O Port



Interface Cable



AC/DC Power
Supply Adapter



AC/DC power Supply
Adapter Power Cord.



Paper Roll




Software
Driver CD

PRINTER SETUP


Install Thermal Paper Roll:

- Open printer cover
- Place paper roll in printer with cut edge down facing forward.
- Pull-out some paper.
- Close cover. Press down. Avoid error position of paper roll.



Self-Checking Test Function - Determine if printer operates normally.

1. Connect the Power Supply Adapter to the POS Printer
 - a. Connect the Power Supply Adapter Cord to the AC wall outlet.
 - b. Connect the Power Supply Adapter Cord to the AC/DC Power Supply Adapter.
 - c. Connect the Power Supply Adapter Cord to the Printer.
2. Make sure printer power is OFF (see Power Switch below).
3. Press FEED button. (see Control Panel below).
4. While FEED button is pressed switch power to ON.
5. The Self-Check List prints.



Connect the Printer to the POS Terminal

1. Connect applicable IFC to the applicable I/O connector port in back of the printer.
2. Connect other end of the IFC to the applicable connector port on POS terminal

Connect the Cash Drawer (RJ11, 12VDC) to the POS Printer

1. Connect cash drawer interface cable to cash drawer RJ11(F) connector port.
2. Connect other end of interface cable to RJ11(F) connector port in cash drawer.


Install Driver Software - Insert the Driver CD into the POS terminal disc drive. Printer installation menu appears. Follow installation procedures.

PRINTER OPERATION

Power Switch - ON/OFF Button is located on the front side of the printer

Control Panel:

1. POWER Indicator appears when printer is connected to the power supply.
2. ERROR Indicator appears as follows:
 - a. When printer overheats.
 - b. When paper roll is in low supply.
 - c. When paper roll cover is installed incorrectly.
 - d. When paper jams ERROR Indicator flashes. See Fix Paper Jam.
3. PAPER Indicator appears when paper roll is in low supply and/or paper is installed backwards.
4. FEED Button feeds paper as required.



FIX PAPER JAM

1. Power OFF printer.
2. Wait for the print head to cool if it has just finished printing.
3. Remove paper jam.
4. Reload the paper roll & close cover.
5. Power ON printer.



FEATURES & FUNCTIONS - User may change print settings from the factory default selected rules as required.

Description	Factory Default ¹	Print Setting Menus ²
Cash Drawer		
Open Cash Drawer	x	
Closed Cash Drawer	-	
Open Cash Drawer After Printing	-	
Open Cash Drawer Before Printing	x	
Print Density		
Regular	x	
Dark	-	
Character Code		
North America, European	-	
North America, European, Asia	x	
Characters per Line		
42 Characters	-	
48 Characters	x	
Baud Rate - Parallel Interface	-	
Copy Count - Set up to 9 copies	1	
1. Factory Default is the designated setting of a particular feature & function. 2. Print Settings Menus change the factory primary rules.		

PRINTER MAINTENANCE

Notes

1. Power OFF printer when performing for any maintenance.
2. Do not touch the surface of the print head with your hands or metal object
3. Do not scratch the surface of the print head, sensor or print roll with tweezers, etc.
4. Do not use oil or acetone for any maintenance.
5. Close cover. Power ON printer after absolute ethyl alcohol is completely vaporized.

Print Head / Paper Roll

Clean print head when the following conditions occur:

1. Printing is not clear.
2. Some longitudinal columns on the paper print out are vague.
3. Loud noise when feeding.

Procedures for maintaining the print head:

1. Power OFF printer and open the top cover. Remove the paper if necessary.
2. Wait for the print head to cool if it has just finished printing.
3. Use the cotton cloth. Dip it in absolute ethyl alcohol to clean the print head surface.
4. Close cover. Power ON printer after absolute ethyl alcohol is completely vaporized.

Service & Technical Support - www.ecomsolution.com